

Wellbore Applications

1. ESP configuration, using Perf Sub-Packer-Tubing Screen with 71' Dip Tube-Vortex Sand Shield and Mud joint.
2. Beam pump configuration, Super Gas & Sand Shield 50' Dip Tube- Vortex Sand Shield-Mud joint.
3. PCP configuration, Tubing Screen 25' Dip Tube-Vortex Sand Shield-Mud joint-Chemical Screen.

